

Comtrend Modem Setup

To set up your Quadro high-speed Internet connection, please refer to the following diagram:



Connecting the Telephone line

Plug one end of the telephone cord into the **wall jack** (no phone filter on this jack only) then the other end plug into the **Line IN** on your surge protector

With a second telephone cord connect to the **Line OUT** on the surge protector and plug the other end into the **Line** port on your Comtrend modem

Connecting the Ethernet Cable

Connect one end of the Ethernet cable to the **LAN** port on the Comtrend modem and the other end of the Ethernet cable to your **computer's ethernet port**.

Connection to Power

Attach the power adapter to the **surge protector outlet** and the other end to the **power** jack on the back of the Comtrend modem

After all connections have been made, **push the power switch in**, to the on position.

Filtering your telephone lines

For every other phone plug the phone filter into the **telephone Jack** then plug your telephone into the **phone filter**. *Make sure that all phones are filtered.*