


## i-Guide™ Quick Reference Guide

**Quick Menu: Quick And Easy.** ... The Quick Menu<sup>1</sup> offers shortcuts to key i-Guide features. Just press MENU on your remote anytime while using the guide or watching TV, and you'll have easy access to programming like HD, On Demand and Kids, plus key features like Search, Parental Controls and more.




Press the **◀ ▶** on your remote to highlight an option, press OK and you're on your way.



Press MENU button twice for the Main Menu.

**All Access With Main Menu.** Main Menu<sup>1</sup> gives you easy access to all features of the guide. Simply press MENU twice, then select from the options including Listings By Time, Search, DVR, Local Weather, Setup and more.



**Enhanced Searching.** With i-Guide find what you want easily by searching Listings By Time, Listings By Channel or by program category. You can also search by category or program title. The Search Menu is easily accessed from the **Q** on the Quick Menu or from the Main Menu.




...When searching by category such as Movies, Sports or Kids, you can focus your search further by subcategories. For example, search for movies that fit your mood by Comedy, Drama, Musicals and more.

**Program Information At Your Fingertips.** i-Guide provides Instant Information while you view program listings, including program title, start/end time, program rating and a brief description including TV content ratings. You'll also see helpful indicators that identify settings, such as Reminders, Recordings and Favorites.



For more detailed information, press the INFO button on your remote.



Blue – Regular programs  
Purple – Movies  
Green – Sports  
Light Blue – Children's programs

**Easy-To-Understand Listings.** TV Listings appear in a grid format with channel numbers and network call letters down the left side and times along the top. Listings are color coded to help you identify different types of programs.



When you find a program you like, press OK to make the Flip Bar disappear or press INFO for more program details.

The Mini Guide lets you watch television and view listings without having to leave your program. To access, press OK or INFO then use the **◀ ▶** buttons to browse time and use the **▲ ▼** buttons to browse channels.



**Action Icon Shortcuts.** Press INFO to learn more about a program. From this Program Information screen, you can use the Action Icons at the bottom to set a Recording or Reminder, set up Parental Controls and more.




Use the arrow **◀ ▶** buttons to highlight an icon, a description will appear just below the icons.

...Smart Channel Surfing. The Flip Bar lets you see program information as you change channels.

**Parental Controls To Protect Your Family.** Parental Controls allow you to restrict viewing and purchases of TV programs based on your preferences. Set a personalized 4-digit PIN to place locks on selected movie and TV ratings, TV content ratings, channels and titles. You can also hide adult titles from being displayed on screen.



Select **Parental Controls** from the Quick Menu to set up Parental Controls and PINs.



**Go Ahead, Play Favorites.** i-Guide's Favorites feature lets you design up to five Favorites lists – one for everyone in the family. Just select My Favorite Channels from the Main Menu or **Q** from the Quick Menu.

