


Quick Reference Guide for Q tv Remote



1 TV Input Select Source

2 TV / AUX Power / Standby

3 RED: Recordings
GREEN: All Shows Guide
YELLOW: Filter Guide Options
BLUE: All Movies Guide

4 A: 36 Hour Lookback
B: Last Channels Watched
C: Settings

5 ◀▶ Fast Forward / Rewind
⏸ Play / Pause
⏹ Stop / Record

6 Apps Shortcut

7 Navigation / OK

8 **VOLUME (Up or Down):**
Increases or decreases volume levels on your audio device(s).

9 **CHANNEL (Up or Down):**

10 Launches Android TV main menu including access to Apps.

11 Displays the last 15 items that have been watched.

12 **BACK/EXIT:**
Returns to previous menu or state within current App. From live video, this key opens the Main Menu.

13 **GUIDE:**
Launches the Channel GUIDE within the App.

14 **ARROWS:**
Moves to highlight items in respective direction.

15 **OK/SELECT:**
Short Press - Confirms a selection. When watching video in the App, info on the current video playing appears, including the shift bar.
Long Press - Invokes the App search menu. This is the same function as the magnifying glass in the Main Menu.

16 **SHOWS:**
Launches the SHOWS play list in the App.

17 **MOVIES:**
Launches the MOVIES play list in the App.

18 **SEARCH/VOICE:**
🔍 Launches text-based Google Assistant search.
🗎 Launches voice-based Google Assistant search.

19 **RECORD:**
Begin recording selected content in the App.

20 **REWIND:**
Fast rewind VOD, or live TV.

21 **FAST FORWARD:**
Fast forwards recorded items.

22 **PAUSE/PLAY:**
Play or pause toggle of VOD, or live TV.

23 **0-9:**
Enter channel numbers in the GUIDE or full screen video.

24 **SET:**
Setup the remote to control the TV, and to program an audio device with Infrared (IR) commands.

1 TV/AUX
2 Power
3 Record (Red), All Shows (Green), Filter (Yellow), All Movies (Blue)
4 A, B, C
5 Fast Forward, Play/Pause, Stop/Record
6 Apps
7 Navigation (Left, Right, Up, Down, OK)
8 Volume (Up, Down)
9 Channel (Up, Down)
10 Home
11 Last
12 Back/Exit
13 Guide
14 Arrows
15 OK/Select
16 Shows
17 Movies
18 Search/Voice
19 Record
20 Rewind
21 Fast Forward
22 Pause/Play
23 0-9
24 Set

KURV 2.0 Voice Remote Control Shown

QUICK START

To begin enjoying your **Q tv FROM Quadro** TV service, please follow these Quick Start instructions. For further assistance, please contact us at 519.229.8933, Option 1 for Support. Visit www.quadro.net/tv for additional user manuals.

1. Power on the television on the Qtv Set Top Box (STB).
2. Access the Channel Guide by pressing the **Guide** button. To exit, press **Back/Exit** twice.
3. Move around the Q tv Guide with the Arrow buttons and make selections with Select/OK button.

*To return to the Q tv App, select Menu, Live, Last, Guide, Shows or Movies.

Q tv FROM QUADRO FEATURES

CHANNEL GUIDE:

View other channels: Press up or down **Arrows** buttons to go lower or higher in the guide.

View other times: Press left or right **Arrows** buttons to go forward or return to current time.

Tune to a channel: Press **Select/OK** button to see program details. Press **Select/OK** again to tune to program.

RESTART:

Restart allows you to start a program that is already in progress from the beginning.

From Play from the beginning pop-up: Press **Select/OK** button.

From a program: Press **Select/OK** button, use **Arrows** buttons to highlight **Restart**, press **Select/OK**.

RECORD:

From the guide: Press **Record** button. If prompted, choose 'Record this episode only' or 'Record all episodes' based on preference.

From a program: Press **Record** button. If prompted, choose 'Record this episode only' or 'Record all episodes' based on preference.

ACCESS RECORDINGS:

Press **Menu** button, use **Arrows** buttons to highlight Profile (left of Search) and press **Select/OK** button.

**Note: You can view your used recording space in the upper right corner.*

AUDIO/SUBTITLE (CLOSED CAPTION):

Press **Select/OK** button, use **Arrows** buttons to highlight Audio. Subtitle, press **Select/OK** button.

ACCESS REPLAY TV:

Open the **Guide**, find the desired channel, press **Left Arrow** to see and highlight **Replay**, and press **Select/OK** button.

PARENTAL CONTROLS:

Press **Menu** button, use **Arrows** button to highlight Profile (left of Search), press **Select/OK**, use **Arrows** button to highlight **Settings** (hear in upper-right corner), press **Select/OK**, highlight **Parental Controls**, and press **Select/OK**.

*For detailed Installation and Operators Guides,
please visit www.quadro.net/qtv*